

**Hex Lag Screw 1/4 x 3"**  
(C-Channel to Fascia)

One or Two on Every Foot to  
Connect the C-channel to the  
Fascia Board.



**Tek Screw #14 x 3/4 (C-Channel)**

Tek #14 x 3/4" to Connect  
C-Channel to to Panel



**Tek Screw #12 x 3/4 (Fascia)**

Tek #12 x 3/4" to Connect  
Fascia to Panel



**Hex Bolt 3/8 x 4" (Beam/Column)**

Two 3/8 x 4" Bolts for Each  
Beam to Colum Connection



**Tek Screw #14 x 4"**  
(Panel to Colum)



Four Tek #14 x 4" for Each Panel  
Connect Panel to Beam

